



THE **GREEN CHOICE** A BETTER KIND OF WOOD FENCE

HOW TO: Cover an Existing Chainlink Fence

TOOLS NEEDED:



OR



14 OR 16 GAUGE
GALVANIZED
STEEL TIE WIRE

ZIP TIES

PLIERS

BAMBOO
FENCING

- 1.** First straighten out any kinks or humps in your chain link fence in order to get a flat fence.
- 2.** Attach your Cali Bamboo panels by simply rolling out the panel flush against the fence. Snip your tie wire into 6 inch pieces.
- 3.** Slip the tie wire around the cane and twist it around the chain link until snug. Cut off the remains if you like. Do this at the top and bottom until the bamboo is secure. That's it!!



BEFORE



AFTER