



THE **GREEN CHOICE** A BETTER KIND OF WOOD FENCE

HOW TO: Dress Up Concrete, Brick, or Stucco

TOOLS NEEDED:



2 ³/₄ IN.
CONCRETE
SCREWS



CONCRETE
DRILL BIT



TREATED
2 x 4s



BAMBOO
FENCING

First you will be anchoring your 2x4s to the wall running horizontally. One will be attached near the top and one near the bottom.

It is important to make sure your 2x4s are running level along the wall. You can use an existing mortar line or just use a level and make marks on the wall where you are going to attach your 2x4s.

- 1.** Drill a hole through your 2x4 into base material using the drill bit provided with the screws. The depth of the hole must be at least 1/4" deeper than the concrete screw embedment.
- 2.** Insert the point of a concrete screw into the hole and drive the screw in using a nut drive or #3 bit tip. Do not over torque the screw.
- 3.** Fasten three or four screws in each 8' 2x4. This will be plenty.
- 4.** Once you have fastened your 2x4s along the length of the wall you can refer back to step one of the wooden fence installations to attach the bamboo. Done!!



BEFORE



AFTER